

EFC x610 Series

Brake Chopper

Operating Instructions R912007235 Edition 01



Bosch Rexroth AG Brake Chopper

Record of Revision

Edition	Release Date	Notes
DOK-RCON03-EFC*BRAKE**-IT01-EN-P	2017.01	First Release

Version Matching Table

Firmware	Operating Instructions		
01V04	Edition 01		

Copyright

© Bosch Rexroth (Xi'an) Electric Drives and Controls Co., Ltd. 2017

This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Bosch Rexroth (Xi'an) Electric Drives and Controls Co., Ltd. It may not be reproduced or given to third parties without its consent.

Liability

The specified data is intended for product description purposes only and shall not be deemed to be a guaranteed characteristic unless expressly stipulated in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.

Table of Contents

	Pa	age
1	Safety Instructions for Electric Drives and Controls	1
1.1	Definitions of Terms	1
1.2	Explanation of signal words and the Safety alert symbol	2
1.3	General Information	4
1.3.1	Using the Safety Instructions and Passing Them on to Others	4
1.3.2	Requirements for Safe Use	4
1.3.3	Hazards by Improper Use	5
1.4	Instructions with Regard to Specific Dangers	7
1.4.1	Protection against Contact with Electrical Parts and Housings	7
1.4.2	Protective Extra-Low Voltage as Protection Against Electric Shock	
1.4.3	Protection against Dangerous Movements	8
1.4.4	Protection Against Magnetic and Electromagnetic Fields During Op-	4.0
	eration and Mounting	10
1.4.5	Protection against contact with hot parts	10
1.4.6	Protection during handling and mounting	11
2	Important Directions for Use	12
2.1	Appropriate Use	12
2.2	Inappropriate Use	12
3	Delivery and Storage	13
3.1	Product Identification	13
3.1.1	Packing Nameplate	13
3.1.2	Product Nameplate	14
3.2	Visual Inspection	14
3.3	Scope of Supply	14
3.4	Transport of the Components	15
3.5	Storage of the Components	15
4	Brake Chopper Overview	16
4.1	Work Principle	16
4.2	Product Features	17
4.2.1	Conditions	17
4.3	Technical Data	18
4.3.1	Electric Data	18
4.3.2	Requirement of Cable Length	18
4.4	Applicable Model of Frequency Converter	18

		Page
4.5	Brake Chopper and Brake Resistor	19
4.5.1	Braking Ratio	19
4.5.2	Recommended Brake Chopper and Brake Resistor	19
5	Brake Chopper Mounting	21
5.1	Installation Conditions	21
5.2	Figures and Dimensions	. 22
5.2.1	Figures	22
5.2.2	Dimensions	22
6	Brake Chopper Wiring	. 23
6.1	System Wiring	23
6.1.1	Electrical Interface	23
6.1.2	Typical Connection Mode 1	. 24
6.1.3	Typical Connection Mode 2	. 24
6.2	Cable Specifications	26
6.2.1	Power Cables	26
6.2.2	Control Cables	28
6.3	Terminals	29
6.3.1	Power Terminals	29
6.3.2	Control Terminals	30
6.3.3	Digital Signal Internal Wiring	32
7	Electromagnetic Compatibility (EMC)	33
7.1	Cable Connections between Brake Chopper and Frequency Convert- er	33
7.2	Mounting and Wiring in Control Cabinet	
7.3	Installing Signal Lines and Signal Cables	
1.3	instailing Signal Lines and Signal Cables	. 33
В	Operating Panel and Dust Cover	
8.1	LED Panel	36
8.1.1	Appearance	36
8.1.2	Operating Descriptions	. 37
3.1.3	Fast Access to Parameters with Button Combinations	37
3.2	LCD Panel	39
8.2.1	LCD Panel Introduction	. 39
3.2.2	Operating Example	40
3.3	Dust Cover	40

Bosch Rexroth AGTable of Contents

	Г	age
9	Parameter and Typical Application	41
9.1	Parameter Descriptions	41
9.1.1	Terminology and Abbreviation in Parameter List	41
9.1.2	Parameter List	41
9.1.3	Parameter Setting Description	43
9.2	Typical Application	48
9.2.1	Quick Start-up at Default Parameter Setting	48
9.2.2	Master / Slave Control Mode	48
10	Diagnosis	49
10.1	Status Code	49
10.2	Warning Code	49
10.3	Error Code	50
10.3.1	Error 01 (OE-b): Brake Chopper Overvoltage	50
10.3.2	Error 02 (OC-b): Brake Chopper Overcurrent	50
10.3.3	Error 03 (SC): Surge Current or Short Circuit	50
10.3.4	Error 05 (OH-b): Brake Chopper Overheat	50
10.3.5	Error 07 (OH-r): Brake Resistor Overheat	51
10.3.6	Error 09 (E.Par): Invalid Parameter Setting	51
10.3.7	Error 10 (idE-): Brake Chopper Internal Error	51
11	Maintenance	52
11.1	Safety Instructions	52
11.2	Daily Inspection	52
11.3	Periodic Inspection	53
11.4	Removable Components Maintenance	54
11.4.1	Disassembly of Dust Cover	54
11.4.2	Disassembly of Fans	55
12	Service and Support	56
13	Environmental protection and disposal	57
13.1	Environmental protection	57
13.2	Disposal	57
14	Appendix	59
14.1	Appendix I: Certification	59
14.1.1	CE	59

Brake Chopper

	F	age
14.1.2	UL	60
14.1.3	EAC	61
14.1.4	EU RoHS	62
14.2	Appendix II: Type Coding	63

1 Safety Instructions for Electric Drives and Controls

1.1 Definitions of Terms

Documentation

A documentation comprises the entire documentation used to inform the user of the product about the use and safety-relevant features for configuring, integrating, mounting, installing, commissioning, operating, maintaining, repairing and decommissioning the product. The following terms are also used for this kind of documentation: Operating Instructions, Instruction Manual, Commissioning Manual, Application Description, Assembly Instructions, Project Planning Manual, Safety Notes, Product Insert, etc.

Component

A component is a combination of elements with a specified function, which are part of a piece of equipment, device or system. Components of the electric drive and control system are, for example, supply units, drive controllers, mains choke, mains filter, motors, cables, etc.

Control System

A control system comprises several interconnected control components placed on the market as a single functional unit.

Device

A device is a finished product with a defined function, intended for users and placed on the market as an individual piece of merchandise.

Electrical Equipment

Electrical equipment encompasses all devices used to generate, convert, transmit, distribute or apply electrical energy, such as electric motors, transformers, switching devices, cables, lines, power-consuming devices, circuit board assemblies, plug-in units, control cabinets, etc.

Electric Drive System

An electric drive system comprises all components from mains supply to motor shaft; this includes, for example, electric motor(s), motor encoder(s), supply units and drive controllers, as well as auxiliary and additional components, such as mains filter, mains choke and the corresponding lines and cables.

Installation

An installation consists of several devices or systems interconnected for a defined purpose and on a defined site which, however, are not intended to be placed on the market as a single functional unit.

Machine

A machine is the entirety of interconnected parts or units at least one of which is movable. Thus, a machine consists of the appropriate machine drive elements,

as well as control and power circuits, which have been assembled for a specific application. A machine is, for example, intended for processing, treatment, movement or packaging of a material. The term "machine" also covers a combination of machines which are arranged and controlled in such a way that they function as a unified whole.

Manufacturer

The manufacturer is an individual or legal entity bearing responsibility for the design and manufacture of a product which is placed on the market in the individual's or legal entity's name. The manufacturer can use finished products, finished parts or finished elements, or contract out work to subcontractors. However, the manufacturer must always have overall control and possess the required authority to take responsibility for the product.

Product

Examples of a product: Device, component, part, system, software, firmware, among other things.

Qualified Persons

In terms of this application documentation, qualified persons are those persons who are familiar with the installation, mounting, commissioning and operation of the components of the electric drive and control system, as well as with the hazards this implies, and who possess the qualifications their work requires. To comply with these qualifications, it is necessary, among other things,

- 1) to be trained, instructed or authorized to switch electric circuits and devices safely on and off, to ground them and to mark them
- 2) to be trained or instructed to maintain and use adequate safety equipment
- 3) to attend a course of instruction in first aid

User

A user is a person installing, commissioning or using a product which has been placed on the market.

1.2 Explanation of signal words and the Safety alert symbol

The Safety Instructions in the available application documentation contain specific signal words (DANGER, WARNING, CAUTION or NOTICE) and, where required, a safety alert symbol (in accordance with ANSI Z535.6-2011).

The signal word is meant to draw the reader's attention to the safety instruction and identifies the hazard severity.

The safety alert symbol (a triangle with an exclamation point), which precedes the signal words DANGER, WARNING and CAUTION, is used to alert the reader to personal injury hazards.

A DANGER

In case of non-compliance with this safety instruction, death or serious injury will occur.

A WARNING

In case of non-compliance with this safety instruction, death or serious injury could occur.

A CAUTION

In case of non-compliance with this safety instruction, minor or moderate injury could occur.

NOTICE

In case of non-compliance with this safety instruction, property damage could occur.

1.3 General Information

1.3.1 Using the Safety Instructions and Passing Them on to Others

Do not attempt to install and operate the components of the electric drive and control system without first reading all documentation provided with the product. Read and understand these safety instructions and all user documentation prior to working with these components. If you do not have the user documentation for the components, contact your responsible Bosch Rexroth sales partner. Ask for these documents to be sent immediately to the person or persons responsible for the safe operation of the components.

If the component is resold, rented and/or passed on to others in any other form, these safety instructions must be delivered with the component in the official language of the user's country.

Improper use of these components, failure to follow the safety instructions in this document or tampering with the product, including disabling of safety devices, could result in property damage, injury, electric shock or even death.

1.3.2 Requirements for Safe Use

Read the following instructions before initial commissioning of the components of the electric drive and control system in order to eliminate the risk of injury and/or property damage. You must follow these safety instructions.

- Bosch Rexroth is not liable for damages resulting from failure to observe the safety instructions.
- Read the operating, maintenance and safety instructions in your language before commissioning. If you find that you cannot completely understand the application documentation in the available language, please ask your supplier to clarify.
- Proper and correct transport, storage, mounting and installation, as well as care in operation and maintenance, are prerequisites for optimal and safe operation of the component.
- Only qualified persons may work with components of the electric drive and control system or within its proximity.
- Only use accessories and spare parts approved by Bosch Rexroth.
- Follow the safety regulations and requirements of the country in which the components of the electric drive and control system are operated.
- Only use the components of the electric drive and control system in the manner that is defined as appropriate. See chapter "Appropriate Use".
- The ambient and operating conditions given in the available application documentation must be observed.
- Applications for functional safety are only allowed if clearly and explicitly specified in the application documentation "Integrated Safety Technology". If this is not the case, they are excluded. Functional safety is a safety concept in

which measures of risk reduction for personal safety depend on electrical, electronic or programmable control systems.

The information given in the application documentation with regard to the use
of the delivered components contains only examples of applications and suggestions.

The machine and installation manufacturers must

- make sure that the delivered components are suited for their individual application and check the information given in this application documentation with regard to the use of the components,
- make sure that their individual application complies with the applicable safety regulations and standards and carry out the required measures, modifications and complements.
- Commissioning of the delivered components is only allowed once it is sure that the machine or installation in which the components are installed complies with the national regulations, safety specifications and standards of the application.
- Operation is only allowed if the national EMC regulations for the application are met.
- The instructions for installation in accordance with EMC requirements can be found in the section on EMC in the respective application documentation.
 - The machine or installation manufacturer is responsible for compliance with the limit values as prescribed in the national regulations.
- The technical data, connection and installation conditions of the components are specified in the respective application documentations and must be followed at all times.

National regulations which the user must take into account

- European countries: In accordance with European EN standards
- United States of America (USA):
 - National Electrical Code (NEC)
 - National Electrical Manufacturers Association (NEMA), as well as local engineering regulations
 - Regulations of the National Fire Protection Association (NFPA)
- Canada: Canadian Standards Association (CSA)
- Other countries:
 - International Organization for Standardization (ISO)
 - International Electrotechnical Commission (IEC)

1.3.3 Hazards by Improper Use

 High electrical voltage and high working current! Danger to life or serious injury by electric shock!

- High electrical voltage by incorrect connection! Danger to life or injury by electric shock!
- Dangerous movements! Danger to life, serious injury or property damage by unintended motor movements!
- Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electric drive systems!
- Risk of burns by hot housing surfaces!
- Risk of injury by improper handling! Injury by crushing, shearing, cutting, hitting!
- Risk of injury by improper handling of pressurized lines!

1.4 Instructions with Regard to Specific Dangers

1.4.1 Protection against Contact with Electrical Parts and Housings



This section concerns components of the electric drive and control system with voltages of **higher than 50 V**.

Contact with parts conducting voltages above 50 V can cause personal danger and electric shock. When operating components of the electric drive and control system, it is unavoidable that some parts of these components conduct dangerous voltage.

High electrical voltage! Danger to life, risk of injury by electric shock or serious injury!

- Only qualified persons are allowed to operate, maintain and/or repair the components of the electric drive and control system.
- Follow the general installation and safety regulations when working on power installations.
- Before switching on, the equipment grounding conductor must have been permanently connected to all electric components in accordance with the connection diagram.
- Even for brief measurements or tests, operation is only allowed if the equipment grounding conductor has been permanently connected to the points of the components provided for this purpose.
- Before accessing electrical parts with voltage potentials higher than 50 V, you
 must disconnect electric components from the mains or from the power supply unit. Secure the electric component from reconnection.
- With electric components, observe the following aspects:
 - Always wait **30 minutes** after switching off power to allow live capacitors to discharge before accessing an electric component. Measure the electrical voltage of live parts before beginning to work to make sure that the equipment is safe to touch.
- Install the covers and guards provided for this purpose before switching on.
- Never touch electrical connection points of the components while power is turned on.
- Do not remove or plug in connectors when the component has been powered.
- Under specific conditions, electric drive systems can be operated at mains protected by residual-current-operated circuit-breakers sensitive to universal current (RCDs/RCMs).
- Secure built-in devices from penetrating foreign objects and water, as well as from direct contact, by providing an external housing, for example a control cabinet.

High housing voltage and high leakage current! Danger to life, risk of injury by electric shock!

- Before switching on and before commissioning, ground or connect the components of the electric drive and control system to the equipment grounding conductor at the grounding points.
- Connect the equipment grounding conductor of the components of the electric drive and control system permanently to the main power supply at all times. The leakage current is greater than 3.5 mA.

1.4.2 Protective Extra-Low Voltage as Protection Against Electric Shock

Protective extra-low voltage is used to allow connecting devices with basic insulation to extra-low voltage circuits.

On components of an electric drive and control system provided by Bosch Rexroth, all connections and terminals with voltages between 5 and 50 volts are PELV ("Protective Extra-Low Voltage") systems. It is allowed to connect devices equipped with basic insulation (such as programming devices, PCs, notebooks, display units) to these connections.

Danger to life, risk of injury by electric shock! High electrical voltage by incorrect connection!

If extra-low voltage circuits of devices containing voltages and circuits of more than 50 volts (e.g., the mains connection) are connected to Bosch Rexroth products, the connected extra-low voltage circuits must comply with the requirements for PELV ("Protective Extra-Low Voltage").

1.4.3 Protection against Dangerous Movements

Dangerous movements can be caused by faulty control of connected motors. Some common examples are:

- Improper or wrong wiring or cable connection
- Operator errors
- Wrong input of parameters before commissioning
- Malfunction of sensors and encoders
- Defective components
- Software or firmware errors

These errors can occur immediately after equipment is switched on or even after an unspecified time of trouble-free operation.

The monitoring functions in the components of the electric drive and control system will normally be sufficient to avoid malfunction in the connected drives. Regarding personal safety, especially the danger of injury and/or property damage, this alone cannot be relied upon to ensure complete safety. Until the integrated monitoring functions become effective, it must be assumed in any case

that faulty drive movements will occur. The extent of faulty drive movements depends upon the type of control and the state of operation.

Dangerous movements! Danger to life, risk of injury, serious injury or property damage!

A **risk assessment** must be prepared for the installation or machine, with its specific conditions, in which the components of the electric drive and control system are installed.

As a result of the risk assessment, the user must provide for monitoring functions and higher-level measures on the installation side for personal safety. The safety regulations applicable to the installation or machine must be taken into consideration. Unintended machine movements or other malfunctions are possible if safety devices are disabled, bypassed or not activated.

To avoid accidents, injury and/or property damage:

- Keep free and clear of the machine's range of motion and moving machine parts. Prevent personnel from accidentally entering the machine's range of motion by using, for example:
 - Safety fences
 - Safety guards
 - Protective coverings
 - Light barriers
- Make sure the safety fences and protective coverings are strong enough to resist maximum possible kinetic energy.
- Mount emergency stopping switches in the immediate reach of the operator.
 Before commissioning, verify that the emergency stopping equipment works.
 Do not operate the machine if the emergency stopping switch is not working.
- Prevent unintended start-up. Isolate the drive power connection by means of OFF switches / OFF buttons or use a safe starting lockout.
- Make sure that the drives are brought to safe standstill before accessing or entering the danger zone.
- Disconnect electrical power to the components of the electric drive and control system using the master switch and secure them from reconnection ("lock out") for:
 - Maintenance and repair work
 - Cleaning of equipment
 - Long periods of discontinued equipment use
- Prevent the operation of high-frequency, remote control and radio equipment near components of the electric drive and control system and their supply leads. If the use of these devices cannot be avoided, check the machine or installation, at initial commissioning of the electric drive and control system, for possible malfunctions when operating such high-frequency, remote control

and radio equipment in its possible positions of normal use. It might possibly be necessary to perform a special electromagnetic compatibility (EMC) test.

1.4.4 Protection Against Magnetic and Electromagnetic Fields During Operation and Mounting

Magnetic and electromagnetic fields generated by current-carrying conductors or permanent magnets of electric motors represent a serious danger to persons with heart pacemakers, metal implants and hearing aids.

Health hazard for persons with heart pacemakers, metal implants and hearing aids in proximity to electric components!

- Persons with heart pacemakers and metal implants are not allowed to enter the following areas:
 - Areas in which components of the electric drive and control systems are mounted, commissioned and operated.
 - Areas in which parts of motors with permanent magnets are stored, repaired or mounted.
- If it is necessary for somebody with a heart pacemaker to enter such an area, a doctor must be consulted prior to doing so. The noise immunity of implanted heart pacemakers differs so greatly that no general rules can be given.
- Those with metal implants or metal pieces, as well as with hearing aids, must consult a doctor before they enter the areas described above.

1.4.5 Protection against contact with hot parts

Hot surfaces of components of the electric drive and control system. Risk of burns!

- Do not touch hot surfaces of, for example, braking resistors, heat sinks, supply units and drive controllers, motors, windings and laminated cores!
- According to the operating conditions, temperatures of the surfaces can be **higher than 60 °C** (140 °F) during or after operation.
- Before touching motors after having switched them off, let them cool down for a sufficient period of time. Cooling down can require **up to 140 minutes!** The time required for cooling down is approximately five times the thermal time constant specified in the technical data.
- After switching chokes, supply units and drive controllers off, wait **15 minutes** to allow them to cool down before touching them.
- Wear safety gloves or do not work at hot surfaces.
- For certain applications, and in accordance with the respective safety regulations, the manufacturer of the machine or installation must take measures to avoid injuries caused by burns in the final application. These measures can

be, for example: Warnings at the machine or installation, guards (shieldings or barriers) or safety instructions in the application documentation.

1.4.6 Protection during handling and mounting

Risk of injury by improper handling! Injury by crushing, shearing, cutting, hitting!

- Observe the relevant statutory regulations of accident prevention.
- Use suitable equipment for mounting and transport.
- Avoid jamming and crushing by appropriate measures.
- Always use suitable tools. Use special tools if specified.
- Use lifting equipment and tools in the correct manner.
- Use suitable protective equipment (hard hat, safety goggles, safety shoes, safety gloves, for example).
- Do not stand under hanging loads.
- Immediately clean up any spilled liquids from the floor due to the risk of falling!

2 Important Directions for Use

2.1 Appropriate Use

Bosch Rexroth products represent state-of-the-art developments and manufacturing. They are tested prior to delivery to ensure operating safety and reliability.

The products can only be used in the appropriate way. Otherwise, situations resulting in property damage and personal injury may occur.



Bosch Rexroth as manufacturer is not liable for any damages resulting from inappropriate use. In such cases, the guarantee and the rights to payment of damages resulting from inappropriate use are forfeited. The user alone carries all responsibility of the risks.

Before using Bosch Rexroth products, make sure that all the pre-requisites for appropriate use of the products are satisfied.

- Personnel that in any way or form use our products must first read and understand the relevant safety instructions and be familiar with appropriate use.
- If the products take the form of hardware, they must remain in their original state, in other words, no structural changes are permitted.
- It is not permitted to decompile software products or alter source codes.
- Do not mount damaged or faulty products or use them in operation.
- Make sure that the products have been installed in the manner described in the relevant documentation.

2.2 Inappropriate Use

Using the brake choppers outside of the operating conditions described in this documentation and outside of the indicated technical data and specifications is defined as "inappropriate use".

Brake choppers shall not be used under following conditions:


- They are subject to operating conditions that do not meet the specified ambient conditions. These include, for example, operation under water, extreme temperature fluctuations or extremely high temperatures.
- Furthermore, the brake choppers shall not be used in applications which have not been expressly authorized by Rexroth. Please carefully follow the specifications outlined in the general Safety Instructions!

3 Delivery and Storage

3.1 Product Identification

3.1.1 Packing Nameplate

Check if the model information on the packing nameplate is the same as you ordered immediately after receipt. If the model is wrong, please contact Bosch Rexroth distributor.




- Product series
- Short text / Type code
- 1234567 Volume
- Net weight
- Material number
- Product version index
- Mass weight

Fig. 3-1: Packing nameplate

- Production week: e.g., 14W20 means week 20 in 2014
- Product QR code
- 10 Serial number
- 11 Manufacturer
- 12 QR code (Internal use) 13 Certification

3.1.2 Product Nameplate

Check if the model information on product nameplate is the same as you ordered immediately after unpacking. If the model is wrong, please contact Bosch Rexroth distributor.



- Brand logo
- Product series
- 3 Short text / Type code
- Technical data

Fig. 3-2: Product nameplate1

- 5 Production week: e.g., 14W20 means week 20 in 2014
- Product QR code 6
- Manufacturer



Certification

Fig. 3-3: Product nameplate2

3.2 Visual Inspection

Check the product for transport damages, e.g. deformation or loose parts, immediately after unpacking. In case of damage, contact the forwarder at once and arrange for a thorough review of the situation.



This is also applicable if the packaging is undamaged.

3.3 Scope of Supply

If any of the following standard supply items is missing, please contact Bosch Rexroth distributor.

- Brake chopper
- Operating Instructions

3.4 Transport of the Components

Description	Symbol	Unit	Value
Temperature range	perature range T _{a_tran} °C		-2570
Relative humidity	-	%	595
Absolute humidity	-	g/m ³	160
Climate category (IEC 721)	-	-	2K3
Moisture condensation	-	-	not allowed
Icing			not allowed

Tab. 3-1: Transport conditions

3.5 Storage of the Components

A CAUTION

Damage to the components caused by long storage periods!

When storing these components for a long period of time, remember to operate them once a year.

Description	Symbol	Unit	Value
Temperature range	rature range T _{a_store}		-2060
Relative humidity	-	%	595
Absolute humidity	-	g/m ³	129
Climate category (IEC 721)	-	-	1K3
Moisture condensation	-	-	not allowed
Icing	-	_	not allowed

Tab. 3-2: Storage conditions

4 Brake Chopper Overview

4.1 Work Principle

Brake chopper is used to consume the electrical energy returned from the external motor to frequency converter during braking, and limit the DC-bus voltage of frequency converter into a rational range to improve the braking performance and finally stop motor quickly. Before the brake chopper is normally running, the start voltage for braking should be properly set according to the selected frequency converter and its load condition, while the stop voltage for braking can be set by parameter H6.03.

When brake chopper is normally running, its control circuit detects the DC-bus voltage in real time. If the bus voltage reaches the pre-set start voltage which can be set by parameter H6.01, brake chopper will start braking during which the electrical energy returned from the motor is consumed by the external braking resistor, and stop braking until the bus voltage reduces to the stop voltage. The braking duty cycle can be adjusted by parameter H6.02. The higher the duty cycle is, the better the braking performance will be. Braking duty cycle should be properly set according to the actual load condition. For example, if the brake resistor overheats, the duty cycle should be appropriately reduced with the premise that the braking performance is satisfied.




Fig. 4-1: Work principle

4.2 Product Features

4.2.1 Conditions

Rated ambient temperature	-1045 ℃		
Derating / ambient temperature	1.5 % / 1 °C (4555 °C)		
Rated storage temperature	-2060 °C		
Rated altitude	≤ 1,000 m		
Derating / altitude	1 % / 100 m (1,0004,000 m)		
Relative humidity	≤ 90 % RH (No condensation)		
Degrees of protection	IP 20		
Degrees of pollution	2 (EN 50178)		
Vibration	$10 \text{ Hz} \le f \le 57 \text{ Hz}$ amplitude: 0.075 mm		
VIDIALIUII	57 Hz < f ≤ 150 Hz acceleration: 1 g		
Mounting mode	Wall mounting		
Coolingtune	Natural cooling		
Cooling type	Enforced air cooling		
Certification	CE, UL, EAC, EU RoHS		

4.3 Technical Data

4.3.1 Electric Data

	Voltage class	3P 380480 VAC (-15 % / +10 %); 50 / 60 Hz (±5 %)		
Bra	ke chopper model	FEAE07.1-EA1-NNNN FEAE07.1-EA2-NNNN		
Input	Output current	0.080.0 A 0.0125.0 A		
and out- put	Brake chopper start voltage	600785 V		
specifi-	Maximum hysteresis	0100 V		
cations	Synchronous signal	Linkage input, Linkage output, up to	3 brake choppers in parallel	
Power supply	DC-bus voltage range	600810 VDC		
	Heat sink overheat	Active when the temperature exceeds the setting point.		
Protection Error output		RELAY junction 0.6 A 125 VAC / 2 A 30 VDC (Ta, Tb are normally open contact)		
	Other protections	Overvoltage protection / Overheat protection / Overcurrent p tection / Short circuit protection		
Terminal	Digital input terminal	5 digital input terminals		
ICIIIIIIai	Digital output terminal	Digital output terminals OUT+, OUT-, one relay output		
Maximum current continuous braking time		0.010.0 s (ED = 10 %)		
Indication functions		Power indication / Error indication / Master-slave indication / Brake indication		

Tab. 4-1: Technical specifications

4.3.2 Requirement of Cable Length

- The cable length between brake chopper and frequency converter is less than or equal to 5 m
- The cable length between brake chopper and brake resistor is less than or equal to 5 m

4.4 Applicable Model of Frequency Converter

Model of brake chopper	Model of frequency converter
FEAE07.1-EA1-NNNN	EFC 5610 3055 kW
FEAE07.1-EA2-NNNN	EFC 5610 75, 90 kW

Tab. 4-2: Applicable model of frequency converter

4.5 Brake Chopper and Brake Resistor

4.5.1 Braking Ratio

Brake resistors with different power ratings are available to dissipate braking energy when the frequency converter is in generator mode. The following table lists the details of brake chopper and brake resistor corresponding to each brake power in the condition that a certain braking ratio is given.

$$ED = \frac{Tb}{Tc} * 100\%$$

ED Braking ratio **Tb** Braking time

Tc Engineering cycle time in application

Fig. 4-2: Braking ratio

4.5.2 Recommended Brake Chopper and Brake Resistor

When braking voltage is 750 V, ED = 10 % and braking torque is 100%, the recommended brake chopper and brake resistor are listed as below.

Brake pow-	Brake chopper type code	Number of	Brake resistence(Ω)		Power of brake resis- tor(KW)		Number of paralleled
er (KW)		brake choppers	Recom- mended value	Min. value	Recom- mended value	Min. value	brake re- sistors
0.4	Internal	-	750	-	0.08	-	1
0.75	Internal	-	750	-	0.08	-	1
1.5	Internal	-	400	-	0.26	-	1
2.2	Internal	-	250	-	0.26	-	1
3.0	Internal	-	150	-	0.39	-	1
4.0	Internal	-	150	-	0.39	-	1
5.5	Internal	-	75	-	0.78	-	1
7.5	Internal	-	75	-	0.78	-	1
11.0	Internal	-	40	-	1.56	-	1
15.0	Internal	-	40	-	1.56	-	1
18.5	Internal	-	32	-	4.80	-	1
22.0	Internal	-	25	-	4.80	-	1
30		1	20	≥8	6.00	≥4	1
37	FEAE07.1-EA1-	1	16	≥8	9.60	≥5	1
45	NNNN	1	13.6	≥8	9.60	≥6	1
55		1	20	≥8	6.00	≥7	2

Brake pow-	Brake chopper type code	Number of	Brake resi	istence(Ω)	Power of brake resistor(KW)		Number of paralleled
er (KW)		brake choppers	Recom- mended value	Min. value	Recom- mended value	Min. value	brake re-
75	FEAE07.1-EA2-	1	13.6	≥5	9.60	≥9	2
90	NNNN	1	20	≥5	6.00	≥10	3

Tab. 4-3: Type selection of brake resistor



- The recommended resistance of the brake resistor is 100 % braking torque, selected according to necessity. If the actually needed torque is not 100 %, the resistance of the brake resistor in the table should be adjusted in inverse proportion, i.e. how much the braking torque increases based on 100 %, the resistance of the brake resistor should decrease by the same amount, vice versa.
- When selecting brake resistor R_b, make sure the current I_c which flows through the resistor is less than the current output ability of the brake chopper. The current I_c through the brake resistor can be calculated by formula I_c = U_d / R_b, in which U_d is the braking operating voltage of brake chopper.
- After the adjustment of the resistance of brake resistor, the power of brake resistor should be also adjusted appropriately. The power can be calculated by formula P_{max} = U_d² / R_b. According to the actual working condition, the braking ratio ED % can be selected to reduce the power of brake resistor reasonably for intermittent braking load. The power of brake resistor can be calculated by formula P_R = k × P_{max} × ED %, in which 'k' is the derating coefficient of brake resistor. The selection of the braking torque should be in general smaller than 150 % of the rated motor torque, or consult the technical support for more information.
- When ED>10 %, the master / slave control mode is recommended (see chapter 9.2.2 "Master / Slave Control Mode" on page 48), or consult the technical support.

5 Brake Chopper Mounting

5.1 Installation Conditions

The brake chopper must be vertically installed.

If one brake chopper is arranged above another, make sure the upper limit of air temperature (55 $^{\circ}$ C) into the inlet is not exceeded. An air guide is recommended between the brake choppers to prevent the rising hot air being drawn into the upper brake chopper if the upper limit of air temperature is exceeded.




Fig. 5-1: Mounting distance and arrangement

d_{hor}: Distance horizontal = 0 mm

d_{top}: Minimum top distance = 125 mm

d_{bot}: Minimum bottom distance = 125 mm

1: Air inlet at brake chopper

2: Air inlet at control cabinet

3: Brake chopper

4: Air outlet at brake chopper

5: Heated air conveying direction

6: Air guide in control cabinet

7: Fan in control cabinet

8: Discharge of heated air

5.2 Figures and Dimensions

5.2.1 Figures




Fig. 5-2: Brake chopper dimensions figure

5.2.2 Dimensions

Model	W	Н	D	w	h	d	Ø	Screw size	Net weight [kg]
FEAE07.1- EA1-NNNN	100	215	149	70	205	140	4.5	M4	2.24
FEAE07.1- EA2-NNNN	100	213	149	70	205	140	4.3	IVI4	2.34

Tab. 5-1: Brake chopper dimensions (unit: mm)

6 Brake Chopper Wiring

6.1 System Wiring

6.1.1 Electrical Interface




Fig. 6-1: Electrical interface of brake chopper

6.1.2 Typical Connection Mode 1




Fig. 6-2: Typical connection mode 1

6.1.3 Typical Connection Mode 2




Fig. 6-3: Typical connection mode 2



- Make sure that terminals (+), (-) of frequency converter are connected to the corresponding terminals P, N of brake chopper respectively. Incorrect connection may damage the brake chopper.
- Please connect to frequency converter directly or install a terminal block.
- The master / slave control mode of the brake chopper supports the following two connections, which currently supports up to three brake choppers in parallel.
 - Two devices: master + slave
 - Three devices: master + slave + slave

6.2 Cable Specifications

6.2.1 Power Cables

Brake chopper	F (-0)	Power	ables installation mode		PE cable	Torque / Screw	
model	Fuse (gG)	B1	B2	E			
		[mm ²]	[mm ²]	[mm ²]	[mm ²]	[N·m / lb·in] (Mx)	
FEAE07.1-EA1-NNNN	100	10.0	10.0	10.0	10.0	1.76 / 15.6 (M4)	
FEAE07.1-EA2-NNNN	160	10.0	10.0	10.0	10.0	1.76 / 15.6 (M4)	

Tab. 6-1: Fuse and cable dimensions for international without USA / Canada

Brake chopper	Fuse (Class J)	Power cables	PE cable	Torque / Screw [N·m / lb·in] (Mx)	
model	ruse (Class J)	[AWG]	[AWG]		
FEAE07.1-EA1-NNNN	100	8	8	1.76 / 15.6 (M4)	
FEAE07.1-EA2-NNNN	175	6	6	1.76 / 15.6 (M4)	

Tab. 6-2: Fuse and cable dimensions for USA / Canada



- The recommended values of the fuse listed in the tables above are based on the **Max. output current**, please select the proper fuse according to the actual application.
- For cable specification for international without USA / Canada,
 ONLY USE copper wires of 90 °C or above with XLPE or EPR insulation according to IEC60364-5-52.
- For cable specification for USA / Canada, ONLY USE copper wires of 75 °C or above according to UL 61800-5-1.


Dimensioning variables of the table values

1. Installation types:

- B1 according to IEC 60364-5-52, e.g. stranded wires routed in cable duct
- B2 according to IEC 60364-5-52, e.g. multi-core line routed in cable duct
- E according to EN 60204-1, e.g. multi-core line routed on open cable tray
- According to NFPA 79 (external wiring), UL 508A (internal wiring), NEC, NFPA 70:
 - 1 cable with 3 conductors, 1 neutral conductor and 1 equipment grounding conductor
 - Routed in pipe on the wall

Internal wiring: Routing inside of control cabinet or of devices.

Field wiring: Routing of cross sections of terminal connectors wired by the user (in the field).



- **B1** Conductors in installation pipes and in installation channels that can be opened
 - e E Cables or lines on open cable trays

Cables or lines on walls

B2 Cables or lines in installation pipes and in installation channels that can be opened

Fig. 6-4: Cable installation types (cf. IEC 60364-5-52; DIN VDE 0298-4; EN 60204-1)

- 2. Recommendation for design of the fuses:
 - International except for USA / Canada: Class gL-gG; 500 V, 690 V; design NH, D (DIAZED) or D0 (NEOZED).



Characteristics

In the case of error (e.g. ground error at connections L+, L-), fuses of characteristic \mathbf{gL} (general-purpose fuse link for cables and lines) and \mathbf{gG} (general-purpose fuse link for general installations) protect the lines in system.

To protect the brake chopper, you can use fuses of characteristic gR.

• USA / Canada: Class J; 600 V

6.2.2 Control Cables

The requirements of control cables are as follows:

Cable	Unit	Min.	Max.			
Туре	Shielded cable					
Wire-end ferrule w/plastic collar	Wire-end ferrule w/plastic collar					
Cross-section	mm ²	1	1			
Closs section	AWG	17	17			
Ferrule length	mm	12	12			
Stripped length	mm	15	15			
Wire-end ferrule w/o plastic collar						
Cross-section	mm ²	1	1.5			
Closs-section	AWG	17	16			
Ferrule length	mm	10	10			
Stripped length	mm	10	10			

Tab. 6-3: Cable requirements



Please follow the steps below for wiring of control terminals.

Step 1: Switch off the brake chopper before performing wiring.

Step 2: Deactivate the control signals in the wiring process.

Step 3: Switch on the brake chopper.

Step 4: Set respective parameters.

Step 5: Activate respective control signals.

6.3 Terminals

6.3.1 Power Terminals




Fig. 6-5: Power terminals

Terminal	Description	
Р	Mains supply input terminals Output terminals	
N		
PB		
P1	Output terminals	

Tab. 6-4: Power terminals description



Fig. 6-6: Grounding and PE terminals

- 1: Power circuit terminal
- 2: Control circuit terminal

6.3.2 Control Terminals

Control terminals figure




Fig. 6-7: Control circuit terminals

A CAUTION

The brake chopper might be damaged!

Please make sure that the power supply of the brake chopper has been switched off before plugging or unplugging the connector.



The terminal block is **ONLY** for wiring convenience, which **CANNOT** be used for fixing the cables. Additional measures need to be taken by users for cable fixing purpose.

Control terminals description

Digital signal terminals

Terminal	Signal function	Description	Signal requirement
IN+		Control signal input terminals	
IN-	Digital inputs	when brake chopper is set to slave	
OUT+	D	Control signal output terminals	
OUT+	Digital outputs	when brake chopper is set to master	Inputs via opto-electric couplers:
Reset	Digital input	Short circuit with COM. Used for error reset	24 VDC, 8 mA / 12 VDC, 4 mA
TG	Digital input	Short circuit with COM. Used for overheat protection of brake resistor	
COM	Shared connection	COM as a reference point, isolation with GND	

Relay signal terminals

Terminal	Signal function	Description	Signal requirement
Ta	Relay changeover con-		Rated capacity:
Tc	tacts	See parameter H6.10	250 VAC. 3 A: 30 VDC. 3 A
Tb	Relay shared contact		250 VAC, 3 A; 30 VDC, 3 A


External power-supply terminals

Terminal	Signal function	Description	Signal requirement
	A '1'	External +24 V supply input for	Rated capacity:
DC_IN*	 Hor control poard 	control and panel boards	24 V (-10+15 %)
		(NOT used for digital inputs)	200 mA
GND	Shared connection	Isolated from COM	_



^{*:} When the brake chopper is powered off, the DC_IN terminal is used to power on the control circuit for viewing and modifying parameters.

6.3.3 Digital Signal Internal Wiring



- Use of terminal TGUse of terminal Reset
- Fig. 6-8: Wiring of terminals TG and Reset



Terminals Reset and TG are using the switching signals. Do not need external power supply.




Fig. 6-9: Wiring of terminals IN and OUT



Terminals IN+, IN-, OUT+ and OUT- are ONLY used in Master / Slave control mode.

7 Electromagnetic Compatibility (EMC)

7.1 Cable Connections between Brake Chopper and Frequency Converter




Fig. 7-1: Cable connections between brake chopper and frequency converter

7.2 Mounting and Wiring in Control Cabinet

Influence of the Motor Power Cable

The longer the motor cable, the greater its leakage capacitors. To comply with a certain EMC limit value, the allowed leakage capacitance of he mains filter is limited.

Run the shortest possible motor power cables.

Routing the Motor Power Cables and Motor Encoder Cables

Route the motor power cables and motor encoder cables along grounded metal surfaces, both inside the control cabinet and outside of it, in order to minimize radiation of interference fields. If possible, route the motor power cables and motor encoder cables in metal-grounded cable ducts.

Route the motor power cables and motor encoder cables

- with a distance of at least d_{min.} = 100 mm to inference-free lines, as well as to signal cables and signal lines (alternatively separated by a grounded distance plate)
- in separate cable ducts, if possible

Routing the Motor Power Cables and Mains Connection Lines

For frequency converters (drive controllers with individual mains connection), route motor power cables and (unfiltered) mains connection lines in parallel for a maximum distance of 300 mm. After that distance, route motor power cables and power supply cables in opposite directions and preferably in separate cable ducts.

Ideally, the outlet of the motor power cables at the control cabinet should be provided in a distance of at least **200 mm** from the (filtered) power supply cable.

The required cable length between frequency converter and brake chopper (or between brake chopper and brake resistor) is less than or equal to 5 m.

7.3 Installing Signal Lines and Signal Cables

Line Routing

The following measures are recommend:

- Route signal and control lines separately from frequency converter power cables, motor power cables and brake chopper power cables with a minimum distance of d_{min.} = 100 mm or with a grounded separating sheet. The optimum way is to route them in separate cable ducts. If possible, lead signal lines into the control cabinet at one point only.
- If signal lines are crossing power cables, route them in an angle of 90° in order to avoid interference injection.
- Ground spare cables, that are not used and have been connected, at least at both ends so that they do not have any antenna effect.
- Avoid unnecessary line lengths.
- Run cables as close as possible to grounded metal surfaces (reference potential). The ideal solution are closed, grounded cable ducts or metal pipes which, however, is only obligatory for high requirements (sensitive instrument leads).
- Avoid suspended lines or lines routed along synthetic carries, because they are functioning like reception antennas (noise immunity) and like transmitting antennas (emission of interference). Exceptional cases are flexible cable tracks over short distances of a maximum of 5 m.

Shielding

Connect the cable shield immediately at the devices in the shortest and most direct possible way and over the largest possible surface area.

Connect the shield of analog signal lines at one end over a large surface area, normally in the control cabinet at the analog device. Make sure the connection to ground/housing is short and over a large surface area.

Connect the shield of digital signal lines at both ends over a large surface area and in short form. In the case of potential differences between beginning and end of the line, run an additional bonding conductor in parallel. This prevents compensating current from flowing via the shield. The guide value for the cross section is 10 mm².

You absolutely have to equip separate connections with connectors with grounded metal housing.

In the case of non-shielded lines belongs to the same circuit, twist feeder and return cable.

8 Operating Panel and Dust Cover

8.1 LED Panel

8.1.1 Appearance




Fig. 8-1: LED panel



- LED panel is optional accessory. The typecode of LED panel is "FPCC02.1-EANN-7P-NNNN", the firmware version of LED panel is 02V08 and above.
- Run button, potentiometer and indicators (Run/FWD/REV) are not used in brake chopper.

8.1.2 Operating Descriptions




Fig. 8-2: Operating mode

8.1.3 Fast Access to Parameters with Button Combinations

Brake chopper provides fast access to parameters within a parameter group with '<Func> + < \rightarrow ' or '<Func> + < \rightarrow ' combinations.

- Press '<Func> + <△>' once, the blinking bit move one bit to left.
- Press '**Func>** + **▼>**' once, the blinking bit move one bit to right.

Example:

Change the value of parameter b0.20 from '0' to '1000', perform the following steps.

- Step 1: press '<Func> + <▲>' or '<Func> + <▼> to active the fast access function, '0' is displayed.
- Step 2: press '**Func> + <▲>**' for three times, move three bits to the left, '0000' is displayed and the left-most '0' is blinking.
- Step 3: press <A> button to change left-most '0' to '1', then '1000' is displayed and '1' is blinking.
- Step 4: press **<Set>** button to save the setting. The screen will return to previous menu and parameter 'b0.10' will be displayed.



- The parameter fast access function is only available to the parameters with a number type setting range, not available to parameters with a optional type setting range.
- Press <Func> button and do not release it until <▲> or <▼> button has been pressed.
- Press <▲> or <▼> button within 2 s if <**Func>** button is pressed.
- If **<Func>** button is pressed and no other buttons be pressed within 2 s, the setting will not take effect.

8.2 LCD Panel

8.2.1 LCD Panel Introduction




Fig. 8-3: LCD panel appearance



LCD panel is optional accessory. The typecode of LCD panel is "FPCC02.1-EANN-LP-NNNN", the firmware version of LCD panel is 01V04 and above.

(1) Rotary encoder

- 1. Scroll between parameter and group code
- 2. Set the parameter value
- (2) Func button: Enter the parameter group screen and go back to previous screens.

(3) Text area: Used for displaying:

- 1. Parameter monitoring screen
- 2. Parameter group / Parameter code
- 3. Parameter name
- 4. Parameter value and unit
- 5. Other screens: Error / Warning display screen, welcome screen, customer information message screen

- (4) Error / Warning information: Error / Warning code will be displayed in this sector. Please refer to chapter 10 "Diagnosis" on page 49.
- (5) Permanent monitoring: By default, its display as "Actual output frequency" is set by parameter U2.09. Value and unit of parameter will be displayed.
- (6) Panel Locked / Unlocked: Panel can be locked by the following ways:
- Setting [U2.02] to '1', or
- Pressing **Func** button with **Loc** button for longer than 3 s.

Panel can be unlocked by the following ways:

- Setting [U2.02] to '0' (only in communication mode), or
- Pressing **Func** button with **Loc** button for longer than 3 s.



Stop button is used to reset error, **Run** button is not used in brake chopper.

8.2.2 Operating Example

Please follow the steps below to set parameter [b0.10] to '1: Restore to default settings' through LCD panel.

- 1. Press Func button.
- 2. Rotate Rotary encoder to select parameter group b0.
- 3. Press Rotary encoder and rotate it to select parameter b0.10.
- 4. Press **Rotary encoder** and rotate it to select parameter value '1: Restore to default settings'.
- 5. Press Rotary encoder to finish setting.

8.3 Dust Cover



Fig. 8-4: Dust Cover



The dust cover is standard accessory.

9 Parameter and Typical Application

9.1 Parameter Descriptions

9.1.1 Terminology and Abbreviation in Parameter List

• Code: Function / parameter code, written in bx.xx, Hx.xx, Ux.xx, dx.xx

Name: Parameter name
Default: Factory default
Min.: Minimum setting step

• Attri.: Parameter attribute

- Run: Parameter setting can be modified when brake chopper is in run or stop status.
- Stop: Parameter setting can only be modified when brake chopper is in stop status.
- **Read:** Parameter setting is read-only and cannot be modified.
- [bx.xx], [Hx.xx], [Ux.xx], [dx.xx]: Function / parameter values

9.1.2 Parameter List

Code	Name	Setting range	Default	Min.	Attri.
		0: Inactive			
b0.10	Parameter initialization	1: Restore to default settings	0	_	Stop
		2: Clear error record			
		0: Inactive			
b0.11	Parameter copy	1: Backup parameters to panel	0	_	Stop
50.11	Tarameter copy	2: Restore parameters from panel	Ü		Сюр
b0.20	User password	0 65,535	0	-	Run
		0: Standalone			
H6.00	Praka shannar mada	1: Master	0		Stop
По.00	Brake chopper mode	2: Master / slave	U	_	Stop
		3: Slave			
H6.01	Brake chopper start voltage	600785 V	750	1	Stop
H6.02	Brake chopper duty cycle	1100 %	100%	1	Stop
H6.03	Brake chopper hysteresis voltage	0100 V	30	1	Stop

Code	Name	Setting range	Default	Min.	Attri.
		0: Brake chopper fault			
H6.10	Relay output selection	1: Brake chopper working	0	_	Stop
		2: Brake chopper ready			
H6.11	Fan control	0: Automatic	0	_	Run
110.11	rancontio	1: Always on	0	_	Null
H6.50	Last error type	_	-	-	Read
H6.51	Second last error type	_	-	-	Read
H6.52	Third last error type	_	-	-	Read
H6.53	DC-bus voltage at last error	_	-	1	Read
H6.54	Braking current at last error	_	-	0.1	Read
H6.55	Power module temperature at last error	_	-	1	Read
d9.00	DC voltage	_	-	1	Read
d9.01	Braking current	_	-	0.1	Read
d9.02	Temperature	_	-	1	Read
d9.05	Relay output	_	-	-	Read
d9.99	Firmware version	_	-	0.01	Read

9.1.3 Parameter Setting Description

b0.10: Parameter initialization

Code	Name	Setting range	Default	Min.	Attri.
b0.10	Parameter initialization	02	0	-	Stop

• 0: Inactive

This parameter will be reset to '0: Inactive' automatically after parameter initialization.

• 1: Restore to default settings

All parameters are restored to factory default settings except for:

H6.50, H6.51, H6.52, H6.53, H6.54, H6.55 (error records).

• 2: Clear error record

Parameter H6.50, H6.51, H6.52, H6.53, H6.54, H6.55 (error records) will be cleared.

b0.11: Parameter copy

This function is used for the same settings of multiple brake choppers via the operating panel.

With this function, users only need set parameters of one brake chopper, and then replicate its settings for all the other brake choppers.

Code	Name	Setting range	Default	Min.	Attri.
b0.11	Parameter copy	02	0	-	Stop

0: Inactive

This parameter will be reset to '0: Inactive' automatically after parameter replication.

• 1: Backup parameters to panel (from source brake chopper to panel)

All parameter settings are copied from the source brake chopper to the operating panel **EXCEPT** that of

- Read-only parameters
- H6.50, H6.51, H6.52, H6.53, H6.54, H6.55 (error records)
- b0.10, b0.11, b0.20
- 2: Restore parameters from panel (from panel to target brake choppers)

All parameter settings are replicated from the operating panel to the target brake choppers **EXCEPT** that of

- Read-only parameters
- H6.50, H6.51, H6.52, H6.53, H6.54, H6.55 (error records)
- b0.10, b0.11, b0.20

b0.20: Password Protection

User password is used to protect parameter settings from unauthorized or unintended changes.

Code	Name	Setting range	Default	Min.	Attri.
b0.20	User password	065,535	0	ı	Run

Possible operations with passwords are as below:

Set user password

The default setting of user password is '0' (inactive). Enter any integer number between 1 and 65,535.

Change user password

Enter the existing user password first, and then modify the value with entering another integer number between 1 and 65,535.

Clear user password

Enter the existing user password or super user password, then user password will be cleared.

H6.00...H6.03: Brake chopper mode

Brake chopper can run under standalone mode, or connect with multiple brake choppers in parallel.

Brake chopper mode is set by inputting function code directly via the panel, not via the jumper cap or pin.

Code	Name	Setting range	Default	Min.	Attri.
		0: Standalone			0.
110 00	Dualta ah amman maa da	1: Master	0 -		
H6.00	Brake chopper mode	2: Master / slave		Stop	
		3: Slave			
H6.01	Brake chopper start voltage	600785 V	750	1	Stop
H6.02	Brake chopper duty cycle	1100 %	100 %	1	Stop
H6.03	Brake chopper hysteresis voltage	0100 V	30	1	Stop

To operate this function, take the following steps:

Step 1: Select brake chopper mode

Braking mode is selected according to the actual application situations, and its default mode is 'Standalone'. When multiple brake choppers run in parallel, the corresponding master or slave mode can be selected.

H6.00 is set to '0: Standalone': when bus voltage is higher than brake chopper start voltage [H6.01], brake chopper starts running. Digital input IN+ is not detected and digital output OUT+ is disabled.

H6.00 is set to '1: Master': when bus voltage is higher than braking start voltage [H6.01], brake chopper starts running. Meanwhile, as the master, brake chopper enables the digital output OUT+ in running status. Digital input IN+ is not detected.

H6.00 is set to '2: Master / slave': when bus voltage is higher than braking start voltage [H6.01], as the slave controlled by input terminal IN+ (closed-loop effective), this brake chopper starts running. It can also be the master which enables the digital output OUT+ in running status.

H6.00 is set to '3: Slave': when bus voltage is higher than braking start voltage [H6.01], as the slave controlled by input terminal IN+ (closed-loop effective), this brake chopper starts running. In this mode, digital output OUT+ is inactive.

Step 2: Set the braking start voltage

Set the braking start voltage according to the actual situations. The default value of EFC model is set to 750 V.

Brake chopper starts running at the pre-set start voltage, and shuts down with a hysteresis voltage (set by H6.03). For example, if parameter H6.01 is set to 750 V, H6.03 is set to 30 V, brake chopper will start braking at 750 V and shut down at 720 V.

Step 3: Set brake chopper duty cycle

Set parameter H6.02 'Brake chopper duty cycle' according to the actual situations. Its default value is 100 %.

When the brake resistor overheats, brake chopper duty cycle can be reduced appropriately. Notice that excessive low brake chopper duty cycle would affect the braking performance.

The diagram of brake chopper duty cycle is shown as below:




Fig. 9-1: Brake chopper duty cycle

In the diagram above, $t1 = t2 \times [H6.02] / 100 \%$; t2 = 50 ms

The diagram of the stop voltage point for brake chopper:

Parameter and Typical Application




Fig. 9-2: Stop voltage point

H6.10: Relay output selection

Please read through the information on 'Wiring diagram' and 'Terminal' before the selection of 'Relay output'.

Code	Name	Setting range	Default	Min.	Attri.
		0: Brake chopper fault			
H6.10	Relay output selection	1: Brake chopper working	0	_	Stop
		2: Brake chopper ready			

• 0: Brake chopper fault

The output is active when an error occurs, inactive when the error is reset.

• 1: Brake chopper working

The output is active when the brake chopper is running.

• 2: Brake chopper ready

After powering on, if no error occurs and not being in braking state, brake chopper is ready for running and the output is active.

H6.11: Fan control

This function is used to set the running mode of the fan for the heat sink.



ONLY model 'FEAE07.1-EA2-NNNN' is equipped with fan units.

Code	Name	Setting range	Default	Min.	Attri.
H6 11	Fan control	0: Automatic	0	_	Run
H6.11 Fan control	Tail Collinoi	1: Always on		_	Null

0: Automatic

The fan for the heat sink is by default switched on / off automatically according to the temperature of the heat sink. In this mode, the noise level of the brake chopper can be reduced.

• 1: Always on

The fan for the heat sink is switched on and running all the time once the brake chopper is powered on. In this mode, a better cooling performance of the brake chopper can be achieved.

H6.50...H6.55: Error parameters

Error parameters which record and indicate the error information are read-only, and can not be modified.

Code	Name	Setting range	Default	Min.	Attri.
H6.50	Last error type	-	-	-	Read
H6.51	Second last error type	-	-	-	Read
H6.52	Third last error type	-	-	-	Read
H6.53	DC-bus voltage at last error	-	-	1	Read
H6.54	Braking current at last error	-	-	0.1	Read
H6.55	Power module temperature at last error	-	-	1	Read

Setting range of H6.50...H6.52:

0: No error

1: OE-b, brake chopper overvoltage

2: OC-b, brake chopper overcurrent

3: SC, surge current or short circuit

4: OL-b, brake chopper overload

5: OH-b, brake chopper overheat

7: OH-r, brake resistor overheat

9: E.Par, parameter settings invalid

10: idE-, brake chopper internal error

d9.00...d9.99: Monitoring parameters

Code	Name	Min. unit
d9.00	DC voltage	1 V
d9.01	Braking current	0.1 A
d9.02	Temperature	1℃
d9.05	Relay output	-
d9.99	Firmware version	0.01

9.2 Typical Application

9.2.1 Quick Start-up at Default Parameter Setting

By default, brake chopper works in **standalone** mode. Its default value of **start voltage** is **750 V** and **duty cycle** is **100 %**.

In standalone mode, when DC-bus voltage reaches to start voltage, brake chopper will start braking with 100 % of duty cycle, which is irrelevant to terminals IN and OUT of the master / slave control mode.

To meet actual requirements, start voltage and duty cycle of brake chopper can be adjusted according to actual situations.



Brake chopper is not equipped with jumper cap or contact pin. All parameters should be set via the panel.

9.2.2 Master / Slave Control Mode

System connection

Please refer to chapter 6.1.3 "Typical Connection Mode 2" on page 24.

Parameter setting

When required braking power is high and singe brake chopper cannot meet requirements, the way to connect multiple brake choppers in parallel (currently support up to 3 choppers) for master/slave control is selected.

Before the brake chopper is powered on, terminals OUT of the master should be connected to terminals IN of the slave. For example, when three brake choppers are connected in parallel, terminals OUT of brake chopper #1 connect to terminals IN of brake chopper #2, and terminals OUT of brake chopper #2 connect to terminals IN of brake chopper #3. Ensure that the connection between master's terminals OUT and slave's terminals IN must be correct. Otherwise the slave will fail to work although the bus voltage reaches to brake chopper start voltage.

Parameter setting paralleled:

The braking mode of the first-level brake chopper is set as 'Master', the second-level set as 'Master / slave', and the third-level set as 'Slave'.

For example, when three brake choppers are connected in parallel, 'H6.00' of brake chopper #1, #2, and #3 should be set to '1', '2', and '3', respectively.

Be noticed that the braking start voltage of the slave should keep consistency with that of the master. Otherwise, it may cause the overload or even breakdown of the brake chopper with relatively low braking start voltage.

Parameter setting:

Brake chopper #1: H6.00 = 1, H6.01 = 750, H6.02 = 100 %

Brake chopper #2: H6.00 = 2, H6.01 = 750, H6.02 = 100 %

Brake chopper #3: H6.00 = 3, H6.01 = 750, H6.02 = 100 %

Diagnosis

10 Diagnosis

10.1 Status Code

Code	Description
1,11,11,11,11,11,11,11,11	During parameter backup

10.2 Warning Code

Code	Description
S.Err	Parameter change blocked
PrSE	Parameter setting contradiction

10.3 Error Code

10.3.1 Error 01 (OE-b): Brake Chopper Overvoltage

Possible reason	Solution
Surge voltage from power supply	Check input power supply
Excessive low resistance of brake resistor	
Excessive high setting of brake chopper start voltage	Adjust start voltage of brake chopper
Wrong wiring of brake resistor	Check the wiring of brake resistor
Damage of brake chopper	Contact with service

10.3.2 Error 02 (OC-b): Brake Chopper Overcurrent

	Solution
Excessive low resistance of brake resistor	Recalculate and choose brake resistor
Wrong wiring of brake resistor	Check the wiring of brake resistor
The power of brake chopper is too small	Choose brake chopper with proper power

10.3.3 Error 03 (SC): Surge Current or Short Circuit

Possible reason	Solution
Earth surge	Remove the short circuit
The power of brake chopper is too small	Choose brake chopper with proper power
Damage of brake chopper	Contact with service

10.3.4 Error 05 (OH-b): Brake Chopper Overheat

Possible reason	Solution	
Brake chopper (heat sink) temperature is higher than max. setting temperature	Reduce ambient temperature, improve ventilation and heat dissipation.	
	Check fan and its power supply connection	
	Adjust power of brake resistor	
Inappropriate setting for duty cycle of brake chopper	Reduce the duty cycle accordingly	
Circuit of temperature detection error	Contact with service	

Diagnosis

10.3.5 Error 07 (OH-r): Brake Resistor Overheat

Possible reason	Solution
Inappropriate type or bad heat of brake	Check power of brake resistor
resistor	Provide good heat condition
temperature sensor of brake resistor error	Check the feedback signal of the resistor's temperature sensor
Inappropriate threshold setting of temperature sensor of brake resistor	Adjust threshold of temperature sensor of brake resistor
Inappropriate setting for duty cycle of brake chopper	Reduce the duty cycle accordingly

10.3.6 Error 09 (E.Par): Invalid Parameter Setting

Possible reason	Solution
Parameter setting invalid after parameter copy	Initialize all parameters

10.3.7 Error 10 (idE-): Brake Chopper Internal Error

Possible reason	Solution
Internal error	Contact with service

11 Maintenance

11.1 Safety Instructions

WARNING

High electric voltage! Risk of death or severe bodily injury by electric shock!

- Only those trained and qualified to work with or on electric equipment are permitted to operate, maintain and repair this equipment.
- Do not operate electric equipment at any time, even for brief measurements or tests, if the equipment grounding conductor is not permanently connected to the mounting points of the components provided for this purpose.
- Before working with electric parts with voltage potentials higher than 50 V, the device must be disconnected from the mains voltage. Ensure that the mains voltage is not reconnected.

11.2 Daily Inspection

Please conduct daily inspection as indicated in the table below in order to prolong the life cycle of brake choppers.

Inspection category	Inspection item	Inspection criteria	Inspection result
	Temperature	-1055 °C (no frost or condensation)	
	Relative humidity	≤ 90 % (no condensation)	
Ambient	Dust, water	No heavy dust or sign of leakage	
conditions	and leakage	(visual inspection)	
	Gas	No strange smell	
	Sound	No strange sound	
	Panel display	No error code	
Brake Chopper	Fan	No blockage or contamination	
Motor	Sound	No strange sound	

Tab. 11-1: Daily inspection list

11.3 Periodic Inspection

In addition to daily inspection, periodic inspection of brake choppers is also necessary. The inspection cycle should be less than 6 months. For operation details, please see table below:

Inspection category	Inspection item	Inspection criteria	Solution
Power supply	Voltago	Charified in namenlate	3P: 380480 VAC
l ower supply	Voltage	Specified in nameplate	(-15 % / +10 %)
Power cable	Power cable	No color change or damage	Replace cable
Signal line	Signal line	Tho color change of damage	Replace signal line
	Crimp terminal		
Terminal	and cable / line	No loose connection	Tighten crimp
connection	Crimp terminal	The loose connection	and terminal screw
	and terminal block		
	Visual	No deformation	Contact with service
	appearance	No deformation	Contact with service
		No color change	Replace fan
	Fan	or deformation	nepiace iaii
Drake chapper		No blockage	Eliminate blockage
Brake chopper		or contamination	and clean fan
	Cooling system	No blockage	Eliminate blockage
	(radiator, inlet, outlet)	or foreign matters	and clear foreign matters
	Printed circuit board	No dust or oil contamination	Clean printed
			circuit board
Accessories	Connection	No loose connection	Tighten terminal screw
	Cable	No color change or damage	Replace cable

Tab. 11-2: Periodic inspection list

11.4 Removable Components Maintenance

11.4.1 Disassembly of Dust Cover




Fig. 11-1: Disassembly of dust cover

- Step 1: Press two buckles as circles indicating in the above figure
- Step 2: Hold dust cover and pull it out horizontally from the mounting plate



Remove the dust cover when use the brake chopper for the first time, install an operating panel to set the related parameters, then disassembly the operating panel and reinstall the dust cover.

11.4.2 Disassembly of Fans




Fig. 11-2: Disassembly of fan



ONLY model 'FEAE07.1-EA2-NNNN' is equipped with fan units.

- Step 1: Unscrew the two screws on the fan cover
- Step 2: Take off the fan cover
- Step 3: Slowly remove the fan
- Step 4: Disconnect fan power wires

12 Service and Support

Our worldwide service network provides an optimized and efficient support. Our experts offer you advice and assistance should you have any queries. You can contact us 24/7.

Service Germany

Our technology-oriented Competence Center in Lohr, Germany, is responsible for all your service-related queries for electric drive and controls.

Contact the Service Helpdesk & Hotline under:

Phone: +49 9352 40 5060 Fax: +49 9352 18 4941

E-mail: service.svc@boschrexroth.de Internet: www.boschrexroth.com

Additional information on service, repair (e.g. delivery addresses) and training can be found on our internet sites.

Service worldwide

Outside Germany, please contact your local service office first. For hotline numbers, refer to the sales office addresses on the internet.

Preparing information

To be able to help you more quickly and efficiently, please have the following information ready:

- Detailed description of malfunction and circumstances resulting in the malfunction
- Type plate name of the affected products, in particular type codes and serial numbers
- Your contact data (phone and fax number as well as your email address)

13 Environmental protection and disposal

13.1 Environmental protection

Production processes

The products are made with energy- and resource-optimized production processes which allow re-using and recycling the resulting waste. We regularly try to replace pollutant-loaded raw materials and supplies by more environment-friendly alternatives.

No release of hazardous substances

Our products do not contain any hazardous substances which may be released in the case of appropriate use. Normally, our products will not have any negative influences on the environment.

Motors
· steel
· aluminum
· copper
· brass

Significant components

Basically, our products contain the following components:

Electronic devices
· steel
· aluminum
·copper
· synthetic materials
· electronic components and modules

magnetic materials
 electronic components and modules

13.2 Disposal

Return of products

Our products can be returned to our premises free of charge for disposal. It is a precondition, however, that the products are free of oil, grease or other dirt.

Furthermore, the products returned for disposal must not contain any undue foreign material or foreign components.

Send the products "free domicile" to the following address:

Bosch Rexroth AG Electric Drives and Controls Buergermeister-Dr.-Nebel-Strasse 2 97816 Lohr am Main. Germany

Packaging

The packaging materials consist of cardboard, wood and polystyrene. These materials can be recycled anywhere without any problem.

For ecological reasons, please refrain from returning the empty packages to us.

Environmental protection and disposal

Batteries and accumulators

Batteries and accumulators can be labeled with this symbol.

The symbol indicating "separate collection" for all batteries and accumulators is the crossed-out wheeled bin.

The end user within the EU is legally obligated to return used batteries. Outside the validity of the EU Directive 2006/66/EC keep the stipulated directives.

Used batteries can contain hazardous substances, which can harm the environment or the people's health when they are improper stored or disposed of.

After use, the batteries or accumulators contained in Rexroth products have to be properly disposed of according to the country-specific collection.

Recycling

Most of the products can be recycled due to their high content of metal. In order to recycle the metal in the best possible way, the products must be disassembled into individual modules.

Metals contained in electric and electronic modules can also be recycled by means of special separation processes.

Products made of plastics can contain flame retardants. These plastic parts are labeled according to EN ISO 1043. They have to be recycled separately or disposed of according to the valid legal requirements.

14 Appendix

14.1 Appendix I: Certification

14.1.1 CE

Declaration of conformity

For Brake Choppers, there are declarations of conformity which confirm that the devices comply with the applicable EN Standards and EC Directives. If required, you may ask our sales representative for the declarations of conformity.

EU directives	Standards
Low-Voltage Directive 2014/35/EU	EN 61800-5-1 (IEC 61800-5-1: 2007)
EMC Directive 2014/30/EU	EN 61800-3 (IEC 61800-3: 2004+A1: 2012)

Tab. 14-1: EU directives and standards

CE label



Fig. 14-1: CE label

High-voltage test

According to standard EN 61800-5-1, brake chopper components are tested with high voltage.

14.1.2 UL

Brake Choppers are listed by UL "Underwriters Laboratories Inc.[®]". You can find the evidence of certification on the Internet under http://www.ul.com under "Certifications" by entering the file number or the "Company Name: Rexroth".

UL listing



Fig. 14-2: UL listing

UL standard

UL 61800-5-1

Company name

BOSCH REXROTH (XIAN) ELECTRIC DRIVES AND CONTROLS CO., LTD.

Category name

Power Conversion Equipment

File number

E328841

UL ratings

For using the components in the scope of UL, take the UL ratings of the individual component into account.

An appropriate fuse must be used, which rating shall be equal to or greater than the SCCR (10,000 Arms) of the power supply being used.

Wiring material UL

In the scope of UL, use only copper conductors rated 75 °C or above.

Requirements for United States / Canadian installations (UL/cUL):

Suitable for use on a circuit capable of delivering not more than 10,000 Arms Symmetrical Amperes, 480 VAC maximum, when protected by UL/cUL-certified Class J fuses only. Power cable use 75 °C or above copper wire.

For Canadian (cUL) installations the drive mains supply must be fitted with any external recommended suppressor with the following features:

- Surge-protective devices; device shall be a Listed Surge-protective device (Category code VZCA and VZCA7)
- Rated nominal voltage 480/277 VAC, 50/60 Hz, 3-phase
- Clamping voltage VPR = 2,000 V, IN = 3 kA min, MCOV = 508 VAC, SCCR = 10,000 A
- Suitable for Type 2 SPD application
- Clamping shall be provided between phases and also between phase and ground

14.1.3 EAC

Brake Choppers have EAC certification. EAC marking is required for Custom Union, including Russia, Belarus and Kazakhstan.

EAC marking



Fig. 14-3: EAC marking

14.1.4 EU RoHS

The product meet the requirement of RoHS (Restriction on the use of certain Hazardous Substances) directive 2011/65/EU with the exemption per Annex of 2011/65/EU.

EU RoHS marking



Fig. 14-4: EU RoHS marking

14.2 Appendix II: Type Coding




Fig. 14-5: Brake chopper type coding




Fig. 14-6: Operating panel type coding

Notes



Bosch Rexroth (Xi'an)

Electric Drives and Controls Co., Ltd.

No. 3999, Shangji Road,

Economic and Technological Development

Zone, 710021 Xi'an, P.R. China

Phone +49 9352 40 5060 Fax +49 9352 18 4941

service.svc@boschrexroth.de

www.boschrexroth.com



R912007235